



PALLET JACK PARTS

Blue Giant MT-50 Frame



Blue Giant MT-50 Hydraulic Unit



Blue Giant MT-50 Frame

Item#	Part#	Description	Item#	Part#	Description
2	906-0100	Bolt	19	906-0023-P-A	Load Roller Assembly, Black Ultra Poly On Steel Hub W/ Bearings
3	906-0076	Roll Pin	19	906-0023-N-A	Load Roller Assembly, Nylon W/ Bearings
5	906-0074	Lifting Link Shaft, for 27" Jacks	19	906-0023-S-A	Load Roller Assembly, Steel W/ Bearings
6	906-0017	Bushing	20	906-0041	Ball Bearing
7	906-0101	Lifting Link, for 27" Jacks			
8	906-0046	Shoulder Pin			
9	906-0042	Cotter Pin			
10	906-0018	Bushing			
11	906-0048	Washer			
12	906-0085	Push Rod, for 48" Jacks			
13	906-0022	Bushing			
14	906-0004	Exit Roller			
15	906-0095	Load Roller Bracket			
16	906-0015	Push Rod Axle			
17	906-0013	Load Roller Axle			
18	906-0014	Pivot Axle			
19	906-0023-D-A	Load Roller Assembly, Red Ultra Poly On Aluminum Hub W/ Bearings			

Blue Giant MT-50 Hydraulic Unit

Item#	Part#	Description	Item#	Part#	Description	Item#	Part#	Description
1	906-5006	Handle Assembly	18	018-523-99	Ball	906-0078-A-ST		Steer Wheel Assembly (black poly on nylon hub w/bearings)
2	904-0149	Release Lever	19	906-1000	Ball	904-0154		Steer Wheel Assembly (nylon w/bearings)
3	906-0012	Roll Pin	20 A	906-0005	Oil Scraper	57	906-0019	Snap Ring
4	904-0151-NEW	Control rod, complete w/chain	21 A	906-0003	O-Ring	58	906-0055	Hub Cap
	904-0151-OLD	Control rod, complete w/chain (27 1/2" Rod, 35 1/4" Overall)	22	906-0058	Top Nut	KITS A	906-0102	Complete Seal Kit
			23	906-0081	Lifting Piston	HU MT 50		Rebuilt Hydraulic Unit - Exchange
			24	906-0000	Metal Bushing			
5	906-0025	Locking Ring	25 A	906-0051	U-Cup			
6 A	906-0002	O-Ring	26	906-0056	Snap Ring			
7	906-0039	Roll Pin	27	906-0037	Oil Plug			
8	906-0054	Handle Pin	28	906-0035	Pump Housing			
9	906-0057	Bushing	29	906-0071	Roll Pin			
10	906-0072	Circlip	30	906-0089	Thrust Bearing			
11	906-0027	Washer	32	906-0093	Circlip			
12	906-0065	Pump Piston	33	906-0049	Roll Pin			
13 A	906-0026	U-Cup	34	906-0097	Traverse			
14	906-0070	Spring	35	906-0046	Shoulder Pin			
15 A	906-0006	Oil Scraper	36	906-0062	Collar Screw - Long			
16	906-0059	Pump Cylinder	37 A	906-0028	Copper Washer			
17 A	906-0007	Copper Washer						
						56	906-0078-A-HD	Steer Wheel Assembly (red ultra poly on aluminum hub w/bearings)
						38	906-0036	Valve Spring
						39	906-0066	Ball
						40 A	906-0011	Quad Ring
						41 A	906-0009	U-Cup
						42	906-0061	Release Pin
						43	906-0060	Valve Screw
						44	906-0031	Ball
						45	906-0032	Valve Spring
						46	906-0067	Ball
						48	906-0033	Collar Screw - Short
						49	906-0073	Adjusting Nut
						50	906-0080	Lowering Valve Arm
						51	906-0008	Roll Pin
						52 A	906-0030	Copper Washer
						53	906-0029	Screw
						54	906-0077	Steer Wheel Axle
						55	906-0075	Bearing